

Panorama Time/Score Clock Instructions



| | | | | | | | | | | | |
|-----------|------------|------------------|--------------|---------------|---------------|----------------|----------------|-------|---|-------|------|
| OFF | GAME TIME | | PERIOD | HOME SCORE | HOME PEN | GUEST SCORE | GUEST PEN | 1 | 2 | 3 | HORN |
| SETUP | INT MODE | | | HOME SCORE +1 | HOME TOL | GUEST SCORE +1 | GUEST TOL | 4 | 5 | 6 | |
| TEAM NAME | SAVED TIME | | | | HOME SHOTS | | GUEST SHOTS | 7 | 8 | 9 | RUN |
| STATUS | SHIFT | PENALTY STOP RUN | PENALTY HOLD | | HOME SHOTS +1 | | GUEST SHOTS +1 | CLEAR | 0 | ENTER | STOP |

BUTTON SEQUENCES

Team Name:

Press **TEAM NAME** until the cursor is in the correct position for the desired team entry. Use the number pad to enter the letters. Press **ENTER** after each letter.

Game Time:

GAME TIME #minutes **ENTER** #seconds **ENTER** **RUN**

Warm-up, Time Outs, Break Time:

- Use **INT MODE** to ensure that the penalties on the board will save in **GAME TIME**
- To return to game time press **INT MODE**

INT MODE #minutes **ENTER** #seconds **ENTER** **RUN**

Period:

PERIOD # **ENTER**

Score:

HOME SCORE +1 (automatically adds 1 goal on)

OR

HOME SCORE #goals **ENTER**

Penalties During Running Time:

- If running time, then you MUST use the **PENALTY STOP/RUN** button, otherwise the penalty will not appear without stopping the game time.

HOME PEN **PENALTY STOP/RUN** **HOME PEN** #player **ENTER** #min **ENTER** #sec
PENALTY STOP/RUN

- To enter a second penalty while one is already running, use the **PENALTY STOP/RUN**. Do not stop the penalties too early and try to be quick entering the additional ones to avoid lengthening the existing penalty.
 - *Expert tip—hit the **HOME PEN** button twice, quickly. You can avoid using the penalty stop/run button.

Clear Penalty:

HOME PEN **PENALTY STOP/RUN** **HOME PEN** # clear min clear sec clear